


- Click "Connect Device WiFi"
- Waiting for the camera voice broadcast "device is connected to the Internet", the configuration is successful



Wait for the device to automatically jump automatically after a successful Internet connection

Binding successfully jumps this interface edit device name click the complete button

## Intelligent networking

- The camera is powered on and after waiting for about 30 seconds, broadcasting "waiting to receive wireless network information"
- Press the reset key 2 quickly, and the camera will enter the smart network



Add the devices

- On the APP side, select the WiFi network that the camera needs to connect (2.4GHz only) according to the page guidance, enter the WiFi password and go to "Next"



Hearing the voice prompt and click the button. If not hear the voice prompt, initialize the device

Click the WiFi button

- The APP automatically starts connecting to the device. Please approach your phone, device, and router as close as possible. Do not exit the APP

- Waiting for the camera voice broadcast "device is connected to the Internet", the configuration is successful



Wait for the device to automatically jump automatically after a successful Internet connection

Binding successfully jumps this interface edit device name click the complete button

## APP Home



## Real-time preview



## Camera reset description

In the following circumstances, press reset for more than 3 seconds and wait for the camera to sound "Didi", namely the reset, the camera will be unbound

- The camera prompts for "Wireless Password error."
- Changed the account number or password of the wireless router
- Wireless router was replaced with the previous camera connection